



Installation Instructions

The Cybercap is precision made to exactly fit over the top of your existing plastic tailgate top cap. Any hard gouges in the OEM plastic may create a “bump” around the scraped part. Removing any of those “bumps” will help ensure an ideal fit. You may want to pop it on without the adhesive first to see how it fits, then when you’re all ready, finish installation with the adhesive to ensure its security and prevent any unintentional separation. Approximately 5-10 minutes.

Note: When installed, forward facing edge has 1 ¼” depth (taller), ⅞” (shorter) rear facing edge.

- 1) Check OEM plastic tailgate for any jagged dings or edges that stick out. Carefully remove any large edges that extend out from its original shape.
- 2) Clean plastic tailgate top cap surface and inside surfaces of The Cybercap of any dust - for adhesive to have the most strength. Make sure all surfaces are dry before following on to step 3.
- 3) Apply ⅓ to ½ of the adhesive included to either the inside face of The Cybercap or the top surface of the OEM plastic tailgate top cap. Pay attention not to drip adhesive on yourself or your exterior. Over application of adhesive will come out of gaps, do not over apply adhesive.
- 4) Allow adhesive to fully dry for 24 hours.

Removing The Cybercap is as simple as removing the OEM plastic top with The Cybercap still adhered. Replacement Tesla Cybertruck Tailgate parts available if you ever want to go back to OEM look.