



## Installation Instructions

The Cybercap and Cybersails are precision made for exacting fit over the top of your factory plastic tailgate top cap.

Any existing hard gouges in the OEM plastic may create a “bump” around the scraped part. Removing any of those “bumps” will help ensure an ideal fit. You may want to pop it on without the adhesive first to see how it fits, then when you’re all ready, finish installation with the adhesive to ensure its security and prevent any unintentional separation. Our tolerances are extremely tight, so even temperature extremes affect initial installation. If so, stage tailgate in the shade and The Cybercap in the sun. Expansion and contraction will work in your favor, in that case.

Note: When installed, the forward facing edge has 1 1/4” depth (taller), 7/8” (shorter) rear facing edge.

- 1) Check OEM tailgate and/or sails surfaces for any jagged dings or edges that stick out. Carefully remove any plastic that extends from its original shape.
- 2) Clean plastic tailgate top cap surface and inside surfaces of The Cybercap and Cybersails of any dust and grease from transport or handling. Make sure all surfaces are dry before following on to step 3.
- 3) Apply 1/3 to 1/2 of the adhesive included to either the underside face of The Cybercap or Cybersails, OR to the top surface of the OEM plastic tailgate top cap. -Pay attention not to drip adhesive on yourself or your exterior. Over application of adhesive will come out of gaps, do not over apply adhesive.
- 4) Let sit 2-3 hours gently & evenly weighted down, if possible. Allow adhesive to fully dry for 24 hours.

Removing The Cybercap is as simple as removing the OEM plastic top with The Cybercap still adhered. Replacement Tesla Cybertruck tailgate and bed sails parts available if you ever want to go back to factory OEM look.

